

Pan



Model-No. : O.P 21" RUSTIC S. BLUE

Color :



S_Blue

For Pan :

- Please carefully trace the template on the counter top directed.
- Please mark the faucet hole centerline in the counter top.

Material & Tools :

Measure tape, Keyhole or saber saw, Hammer, Glasses, Rags or Paper toweling, Drill (1/2 dia, drill bit or larger), Pencil, Sealant, Sharp knife or scissors.

Design by Snob Sanitary Ware LLP



Make In India

Perfection, Perception, and Performance, when the three combine, gives birth to something new, acceptable, and truly not believed before.