

Table Top



Model-No. : Spenzo art - 007

Color :



Coffee brown

For Table Top :

- Mark and pre-drill the wood screw holes at the locations shown on the template.
- Waterproof any exposed areas of wood.
- Position the counter top upside down on foam padding to protect the surface.
- Mark and drill 3/6" holes 5/8" deep at the locations shown on the template.
- Use a setting tool and hammer to secure the anchors.

Material & Tools :

Measure tape, Keyhole or saber saw, Hammer, Glasses, Rags or Paper toweling, Drill (1/2 dia, drill bit or larger), Pencil, Sealant, Sharp knife or scissors.

Design by Snob Sanitary Ware LLP



Make In India

Perfection, Perception, and Performance, when the three combine, gives birth to something new, acceptable, and truly not believed before.

